



序号 零件编号及名称
Ref.no. Part.no & Description

1	S127齿轮盒Gear Box
2	S129轴承625Drive Gear Metal
3	S130轴承盖Cover For Metal
4	S142护架弹簧片Spring For Guard
5	S143 M2X3十字沉头螺钉Screw
6	B17 ϕ 12X ϕ 6.4X1.6平垫Washer
7	B16 M6X5.2螺母Nut
8	B10润滑油杯Grease Cup
9	B9油杯盖Cap For Oil Cup
10	S158 M4X8十字沉头螺丝Standard Screw
11	S128 M4X2.5内六角沉头螺钉Standard Screw
12	S141刀片护架Knife Guard
13	B104安全片螺钉Screw For Plate
14	S144安全片Safety Plate
15	S157导向架Standard
16	B116分布片Guide Plate
17	B26 M2.5X3十字沉头螺丝Standard Screw
18	B118 M5X6.3内六角沉头螺钉Standard Screw
19	S186底座组件Base Plate Assembly
20	S262底座Base Plate
21	B128后滚子轴Roller Shaft(Rear)
22	B129底座滚子Roller
23	B130滚子隔套Roller Collar
24	B125 M3X5带发兰十字沉头螺丝Standard Screw
25	B123前滚子轴Roller Shaft(Front)
26	B124底座前滚子Front Roller
27	B127下刀弹片Pressure Spring For Lower Blade
28	W7 M3X3十字沉头螺丝Standard Screw
29	B178下刀支撑块Lower Blade Holder
30	A50 M3X6十字沉头螺钉Standard Screw
31	S187下刀成套Lower Knife Assembly

序号 零件编号及名称
Ref.no. Part.no & Description

32	B174下刀调节块Lower Knife Adjuster
33	B175调节块螺母Nut
34	S275下刀Lower Knife
35	B177下刀螺母Nut
36	S184蜗轮成套Worm Wheel Assembly
37	S132蜗轮轴Worm Wheel Shaft
38	S13蜗轮Worm Wheel
39	S131-1蜗轮密封圈Washer
40	S134蜗轮套铜垫圈Ring For Gear
41	S135蜗轮轴螺丝Shaft Gear Screw
42	S133蜗轮(八角)Knife
43	S136刀片锁紧螺母For Knife
44	S140油毡Oil Felt
45	S137刀片加油器Knife Oiler
46	S139加油器弹簧Spring For Oiler
47	S138加油器螺丝Screw For Oiler
48	S185砂轮成套Grinder Assembly
49	S154砂轮按钮Grinder Button
50	S151砂轮内轴弹簧Spring
51	S149砂轮内轴Grinder Shaft
52	S153砂轮外轴弹簧Spring
53	S155砂轮架Grinder Base
54	S152砂轮外轴Grinder Collar
55	S150砂轮Grinder Wheel
56	S156 M4X12一字半圆头螺丝Standard Screw
57	S124轴杆Drive Gear
58	C152 ϕ 2.5X14开口销Roll Pin
59	S106波形垫圈Wave Washer
60	S194转子成套组件Rotor Assembly
61	S126 ϕ 29轴承Bearing
62	S167 E形 ϕ 10轴用挡圈Shaft Washer

序号 零件编号及名称
Ref.no. Part.no & Description

63	S102转子Rotor
64	S115空气导向盖Air Guide
65	S106定子螺丝Stator Screw
66	S101定子Stator
67	S107电机盖Motor Cover
68	S113插座盒垫片Terminal Plate Washer
69	S111插座盒Terminal Plate
70	S112 M4X21十字沉头螺丝Standard Screw
71	C168插座Terminal
72	S110 M3X10十字沉头自攻螺丝Standard Screw
73	S118碳刷架组件Carbon Brush Base
74	S104碳刷Carbon Brush
75	C106碳刷盖Cap For Carbon Brush
76	G42 M4X8十字沉头螺丝Standard Screw
77	G24 M4X3.2螺母Nut
78	S116手柄Handle
79	S117 M4X20内六角螺丝Standard Screw
80	B164开关Switch
81	S181开关盖Switch Cap
82	S122接线柱Connecting Terminal
83	S119手柄盖Cover For Handle
84	S120 M3X12十字沉头自攻螺丝Standard Screw
85	S106附件全套Additional Assembly
86	C172锁销Lock Shaft
87	S173扳手Spanner
88	S171润滑油Grease Oil
89	B169加油器Oiler
90	S175内六角扳手Spanner
91	C170电源线Cord With Plug